

# Safety Alert

Subject

## FAULTY BURST DISCS

Issue no.

1

Date

7.12.2009

Dräger Safety Pacific has received notification from our cylinder valve supplier (TD Preece) of the supply of a batch of potentially faulty burst discs.

The burst discs in question have been supplied since **November 2008** in any of the following forms:

Complete cylinder valves,  
Individual burst discs or  
300bar (only) compressed air cylinders complete with valves.

The batch of burst discs which have been identified as potentially faulty have the batch number **30/08** stamped into the side as per the burst disc pictured below.



### Directive

Any cylinders found to have had valves fitted with the affected burst discs must be immediately removed from service, have the contents drained and be placed into quarantine.

Additionally any individual valves or burst discs must not be fitted to cylinders and must also be placed into quarantine.

Replacement burst discs will be supplied to any customers who identify discs with the batch numbers indicated above

Should you have any queries please call Draeger Safety Pacific on 1800 67 77 87

Draeger Safety Pacific Pty Ltd  
ABN 96 000 435 549  
Unit 99 / 45 Gilby Road  
Mount Waverley Vic 3149  
Telephone: 1800 677 787  
Fax: 1800 647 484